

Part no.	Designation	A Lubrication width [mm]	B Housing width [mm]	C Space require- ment [mm]
1012180100	RB FK-P-SW 0100	100	135	355
1012180150	RB FK-P-SW 0150	150	185	405
1012180200	RB FK-P-SW 0200	200	235	455
1012180250	RB FK-P-SW 0250	250	285	505
1012180300	RB FK-P-SW 0300	300	335	555
1012180350	RB FK-P-SW 0350	350	385	605
1012180400	RB FK-P-SW 0400	400	435	655
1012180450	RB FK-P-SW 0450	450	485	705
1012180500	RB FK-P-SW 0500	500	535	755
1012180600	RB FK-P-SW 0600	600	635	855
1012180700	RB FK-P-SW 0700	700	735	955
1012180800	RB FK-P-SW 0800	800	835	1055

## Dimensions

