

Part no.	Designation	A Lubrication width [mm]	B Housing width [mm]	C Space require- ment [mm]
1012190100	RB FK-SW 0100	100	135	355
1012190150	RB FK-SW 0150	150	185	405
1012190200	RB FK-SW 0200	200	235	455
1012190250	RB FK-SW 0250	250	285	505
1012190300	RB FK-SW 0300	300	335	555
1012190350	RB FK-SW 0350	350	385	605
1012190400	RB FK-SW 0400	400	435	655
1012190450	RB FK-SW 0450	450	485	705
1012190500	RB FK-SW 0500	500	535	755
1012190600	RB FK-SW 0600	600	635	855
1012190700	RB FK-SW 0700	700	735	955
1012190800	RB FK-SW 0800	800	835	1055

## Dimensions

